



Board Replacement for Engineered Glue-Down Hardwood Floors

November, 2023

Tools



- Adhesive
- Circular saw
- Trowel
- Tapping block
- Vacuum
- Pencil
- Marking pen
- Putty sticks
- Measuring tape
- Dust mask
- Safety glasses
- End nippers
- Knife
- Chisel
- Scraper
- Hammer

Mark the Board to Be Cut



With a marking pen, mark the areas to be cut approximately $\frac{1}{2}$ " from the side joints

Drill Holes at the Corners



Cut the Marked Areas



Care must be taken not to cut into adjoining boards

Set the Saw To Cut The Thickness of the Board



Make a Cut Down the Center for Easy Removal



Carefully Remove the End Pieces



Release the Remaining 1/2" of the Edge From the Adhesive



Scrape Any Remaining Adhesive to a Thin Residue



Mark the Replacement Board to Length



Cut the Board to Length



Remove the Bottom of the Groove on the Side and End



Apply the Adhesive to the Back of the Material with a Notched Spreader



Optional: Place a Bead of Glue on the Top of the Tongue



Insert the Tongue and Drop into Place



Clean and Fill as Necessary



RESOURCES

AHF Products Customer Service Techline
(866)243-2726 M-F 9:00 am – 4:30 pm, EST
ahfproductsupport@ahfproducts.com

www.floorexpert.com